




















14124


Assembly Instruction

		A x 1PC		B x 1PC		C x 1PC	
							
D x 1PC		E x 1PC		F x 1PC		G x 1PC	
							
H x 1PC	J x 1PC	K x 1PC	L x 1PC	M x 1SET			
							
a x 1PC	b x 12PCS		c x 6PCS		d x 2PCS		
							
e x 8PC							
							


STEP 1




STEP 2




STEP 3



STEP 4



STEP 5



STEP 6

